General Care & Safety

Wall plugs supplied are ONLY suitable for solid stone/brick walls. They are not suitable for use in aerated blocks or similar. If fixing to a stud wall, sufficient extra internal reinforcements must be made to the wall. Screws must locate into suitably reinforced studs and noggins.

Take care using power tools - The use of a residual current device (RCD) is recommended. Beware of hidden cables or pipes when drilling.

This product can be dangerous if installed incorrectly. This product must be installed by a qualified plumber or installer. It is the installer's responsibility to check that the fixings are suitable for the installation in hand.

Cistern fittings are suitable for Water pressure: 0.2 - 10 bar. Do not add caustic chemical substances (e.g. containing chlorine compounds or similar) into the cistern. These can damage the valve components and cause failure.

Before starting to enclose the cistern, the system must be first tested for leaks before 2nd fix commences. Temporarily fix the back to wall pan in place and make connections. Turn the water supply on and flush the pan to check for leaks. This is particularly important to do prior to tiling for fully tiled in installations

This cistern is not suitable for use with wall hung pans without the use of a suitable supporting frame.


BS EN 14055: 2010 - CL 2 - 6

Comfort Height Cistern

Fitting Instructions


Please retain for future reference

∆ TR9008 / VCHC820



This product must be installed by a qualified fitter or plumber in accordance with and meet the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004


Parts Included




- Cistern
- **EPS Jacket**
- Conical Seal
- Washer
- Flush Bend Nut
- 6. Flush Pipe
- Rubber Pan Seal
- Bottom Entry Fill Valve
- 2 x Attaching Screws
- Mounting Bracket
- 11. Cistern Cover
- 12. Pneumatic Push-button
- 13. Air Hoses
- 14. Flush Valve


Brought to you by the Roper Rhodes Group Brassmill Lane Trading Estate Bath BA1 3JF t: 01225 303900

V1.AR.230616




Installation Of The Cistern








By adjusting the fill valve the water level can either be increased or decreased accordingly




Adjusting The Flush Volume








Installation With A Front Access Fascia



Installation With A Top Access Fascia



Installation Of Pneumatic Push-button

