


Spares Diagram

## THUCROFT – INST06037, INST06038 & INST06039

	Driver	Driver 2	Transformer	Shaver Socket	USB Socket	Socket Control	Control	Relay	Door Hinge	Hanging Bracket	Wall fixing kit	Securing screw kit	Shelf Supports +	Glass shelf	Left Door	Right Door	Back Panel 1	Back Panel 2	Door Magnet	Left Side Panel	Right Side Panel	
Ref	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	
INST06 037	SP20544	SP20543	SP19941	SP12546	SP20193	SP13236	SP20221	SP18639	SP19955	SP19943	SP20211	SP19585	SP19945	SP19947	SP19950		SP20194	SP20197	SP20235	SP20236	SP20237	
INST06 038		SP20545									SP20212			SP19948	SP19951		SP19953	SP20195				SP20198
INST06 039		SP20213									SP19949			SP19952	SP19954		SP20196	SP20199				


Product component code below:

1 (LED)



SLT60-12VFG-UN

2 (Heated Pad)



SLT30-24VFG  
SLT60-24VFG-UN

3



DC-240-0080T

4



Shaver Socket

5



USB Socket

6




Socket Control

7



IR Sensor

8



TS-002

9



Door Hinge

10



Hanging Bracket

11




Wall Fixing Kit

12



Securing Screw Kit

13



Shelf Supports + Plugs

14



Glass Shelves

15



Left Door

16



Right Door

17




Back Panel 1

18



Back Panel 2

19



Door Magnet

20



Left Side panel

21



Right Side panel